2.2 Beeper and LED notifications

2.2.1 Beeper Volume setting

||| || ||| || ||| ||| |||| |||||

Volume low

||| ||| || ||| ||| ||| ||| |||||

Volume high

2.2.2 Startup beep

||| || ||| || ||| |||| ||| ||| |||

Shut down startup beep

||| || ||| ||||| ||| ||| ||| |||

Open startup beep

2.2.3 Good read beep

||||| ||| || | ||| || ||| | || ||||

Good read beep on

||| || ||| | || ||| | || | | ||||| |

Good read beep off

2.2.4 Beep pitch-good read

||| | ||| || | || || | || ||||| |

Low pitch

||| || || | || ||| | || | || |||| ||

Middle pitch

||| | ||| || | || ||| | || |||| ||| |

High pitch

2.2.5 Beep duration-good read

||| | ||| || | || ||| | || |||||| |

Tone long

||| | ||| || | || ||| | || ||||| ||

Tone pip